

# ***hama***

## Compatibility/ Kompatibilität

### **Samsung** (Android 9/10/11 and higher)

Galaxy A01, Galaxy A2 Core, Galaxy A11,  
Galaxy A20, Galaxy A20s, Galaxy A30,  
Galaxy A51, Galaxy A52, Galaxy A70,  
Galaxy A70s, Galaxy A71, Galaxy A80

Galaxy S8, Galaxy S9, Galaxy S10, Galaxy S10e,  
Galaxy S20, Galaxy S20+, Galaxy S21+

Galaxy M30s

Galaxy Note 9, Galaxy Note 10,  
Galaxy Note 10 Lite, Galaxy Note 10+,  
Galaxy Note 20 Ultra (5G)

### **Apple** (only USB-C models)

Apple iPhone15  
Apple iPhone15 Plus  
Apple iPhone15 Pro  
Apple iPhone15 Pro Max

Apple iPad Air4  
Apple iPad Pro 2022

### **Google** (Android 9/10/11 and higher)

Pixel 3a (XL), Pixel 4, Pixel 4a

### **Xiaomi** (Android 9/10/11 and higher)

Mi 8, Mi 9, Mi 9 SE, Mi 9T, Mi 10 Pro,  
Mi 10 Lite, Mi 11 Lite

Redmi 9, Redmi Note 8, Redmi Note 8 Pro,  
Redmi Note 8T, Redmi Note 9,  
Redmi Note 9 Pro, Redmi Note 9S,  
Redmi Note 10, Redmi Note 10 Pro

### **Huawei**

(Android 9/10/11, HarmonyOS 2.0.0 and higher)

Mate 10, Mate 20 Lite, Mate 20 Pro,  
Mate 30 Pro, Mate 40 Pro

Nova 4, Nova 5i, Nova 7, Nova 7 Pro, Nova 7 SE,  
Nova 7i, Nova 8, Nova 8 Pro, Nova 8 SE,  
P8, P20, P20 Pro, P30, P30 Lite, P30 Pro,  
P30 Pro New Edition, P40 Lite, P50 Pro

Honor Magic 2, Honor 20 Pro, Honor 50,  
Honor Play

### **Note / Hinweis**

Also other devices like LG/ OnePlus/ ZTE/ Sony/  
Lenovo are probably working - some functions  
can be different.

Auch für andere Endgeräte wie LG/ OnePlus/  
ZTE/ Sony/ Lenovo kann das Produkt - mit  
abweichenden Funktionen - verwendet werden.