

## Instructions for use

---

# SPACE

### In the DVD player

1. Insert the cleaning DVD in the DVD player just like a normal disc. Ensure that the cleaning brushes point downwards.
2. Select your preferred language from the 8-language menu.
3. Press the Play button on the DVD player to start the cleaning process or the required system check software by clicking on the appropriate image.
4. During the play time you can also select the previous "M" or the next "m" programme. You can also do this by activating the "MENU" point.

### Note

1. Ensure that your system is Digital 5.1 Channel compatible before the audio system test.  
The "PROLOGIC" test has been developed to test your stereo (or 2-channel) system. The "5.1 Channel" test has been developed to test your Digital 5.1 channel system.



2. The "Audio Frequency Check" tests the connection of the subwoofer and the frequency range. If you have a stereo system or a PROLOGIC system, you will notice that the sound displayed on the screen does not match the actual sound. However, this only affects the function of the frequency test.



### In the DVD-ROM drive:

Important: If you are using a PC ensure that the DVD video driver has been installed.

1. Insert the cleaning DVD in the DVD player just like a normal disc. Ensure that the cleaning brushes point downwards.
2. Select your preferred language from the 8-language menu.
3. Press the Play button on the DVD player to start the cleaning process or the required system check software by clicking on the appropriate image.
4. During the play time you can also select the previous or the next programme by clicking on it.

**Section:**

Logo

Language selection

Menu


1. Cleaning process
2. "PROLOGIC" audio channel test (stereo/2-channel or Prologic)
3. Left channel
4. Right channel
5. All channels (or 5-channel test)
6. 5.1 channel test
7. Mono
8. Stereo
9. 3 Stereo
10. "Discrete"
11. "Quad"
12. 5 channels
13. Audio frequency test
14. Left, centre, right, rear left/right  
500 Hz – 20 kHz
15. Subwoofer 20 Hz – 350 Hz
16. Colour
17. Grey scales
18. Video programme with 5.1 channel sound
19. Helicopter
20. Train
21. End



**DVD Laser Lens Cleaner**



**Audio Frequency Response Check**



**Video Color Fade Check**



**ProLogic Check of Audio Channels**



**5.1 Channel Check of Audio Channels**



**Video With 5.1 Channel Dolby Digital Surround Sound**